




像素线测量工具QR Code Pixel Line Measurement Tool


Step 1:
Scan the QR code and
enter mini program. Click
and log in with phone




Step 2:
Select the
displayed phone
number.



Step 3:
Fill in the blank
with OTP sent to
your message.




Step 6:
You can start
searching for pulse
value in this




Step 5:
Confirm and go
back to home page.



Step 4:
Input 35554.







Step 7:
Choose any
model, input a
pulse value and
start to search.



Step 8:
It says the
membership has
expired. Click the
“Use Balance”.




Step 9:
There are 2
options. Click
the “Top up”
option.




For customers that
have bought our initial
version of Pixel
measurement system,
please contact us and
show this interface of
the mini program. 1
year membership will
be provided for free.



Step 12:
Membership
options include
annual, monthly,
and pay-per-use.



Step 11:
Click the
Membership option.



Step 10:
You can top up any
amount according
to your
requirement.

